

# SPOLJNI SERZOR (QAC 34)



Siemens-ov QAC34 spoljni senzor je dodatni pribor za sve HT kotlove. Priklučuje se na 7 i 8 priključak na M2 konektoru na glavnoj ploči kotla.

Način podešavanja nagiba krive grejanja zavisi od priključenih pribora na kotlu

- 1) Bez pribora: birate krivu grejanja na digitalnim displeju kotla
- 2) sa QAA 73 regulatorom birate krivu grejanja na regulatoru



KHG714072811



## Signali spoljnog senzora

